

# RENAULT Clio Estate 1.6 16v 4AT (110 HP) User Manual

<b>Torque</b>	148 lb-ft @ 1500 RPM
<b>Acceleration 0-62 Mph (0-100 kph)</b>	9.9 s
<b>Power</b>	62 KW @ 3500 RPM
<b>Combined</b>	39 mpg US
<b>Ground Clearance</b>	3.1 in
<b>Wheelbase</b>	98.9 in
<b>Top Speed</b>	136 mph
<b>CO2 Emissions</b>	129 g/km
<b>Tire Size</b>	245/35R20
<b>Highway</b>	53.5 mpg US
<b>City</b>	48 mpg US
<b>Unladen Weight</b>	3494 lbs
<b>Cargo Volume</b>	15.7 cuFT
<b>Displacement</b>	4691 cm <sup>3</sup>
<b>Front</b>	Ventilated 257 x 22D, 54mm floating caliper
<b>Gross Weight Limit</b>	3935.2 lbs
<b>Width</b>	67.8 in
<b>Gearbox</b>	Sequential, 6 Speed
<b>Front/rear Track</b>	63.4/62.2 in
<b>Length</b>	160 in
<b>Height</b>	56.1 in
<b>Cd</b>	0.39
<b>Cylinders</b>	V8
<b>Rear</b>	Solid 251 x 10 D, 38mm floating caliper
<b>Fuel System</b>	Common Rail